


# STRATA 32 TELEVISION CONSOLE Quick Start Guide




## SURFACE COMPONENTS



### CHANNEL STRIPS (x32)




### TOUCHSCREEN PANEL CONTROLS



# STRATA 32 TELEVISION CONSOLE Quick Start Guide



## GIBRALTAR IP MIX ENGINE, REAR PANEL JACKS & CONNECTIONS



## MASTER PANEL CONTROLS

### SUB & VCA (GROUP CONTROLS)

Eight control strips, with an encoder and four buttons (PFL, Cut, TB, and Select) plus half an OLED display per group. Touchscreen Panel *SUB GRP* and *VCA* buttons select which Group controls are shown.

### MASTER 1 & 2 CONTROLS

Dedicated control strips for the Master 1 and Master 2 outputs with a master fader, PFL, Cut, and Select buttons plus one Wild (user-set) button, an OLED display, and a rotary encoder with press-to-take switch.

### MONITOR CONTROLS

Two control columns for the CR and two Studios, includes rotary encoder speaker level controls; Wild Source select buttons; AFL/PFL controls; CR and Studio monitor source selectors; and two OLEDs to display monitor levels and meter selections.

Two USB jacks (Studio column, top) allow a guest User to save and take Events (console setups) to a thumb drive. The Clip jack allows a thumb drive, with 48 kHz .WAV audio files and M3U playlist files, to be accessed using the Touchscreen Panel's Clip Player View.

PFL = Pre-Fade Listen  
AFL = After-Fade Listen  
CR = Control Room  
TB = Talkback  
Cut = Off control for Groups, VCAs, or Master faders  
OLED = Organic Light Emitting Diode  
Select = Selects that control strip to view/edit its settings using Touchscreen Panel controls